



SSE-X3548S/SSE-X3548SR

QoS

User's Guide

Revision 1.14

The information in this USER'S GUIDE has been carefully reviewed and is believed to be accurate. The vendor assumes no responsibility for any inaccuracies that may be contained in this document, makes no commitment to update or to keep current the information in this manual, or to notify any person organization of the updates. Please Note: For the most up-to-date version of this manual, please see our web site at www.supermicro.com.

Super Micro Computer, Inc. ("Supermicro") reserves the right to make changes to the product described in this manual at any time and without notice. This product, including software, if any, and documentation may not, in whole or in part, be copied, photocopied, reproduced, translated or reduced to any medium or machine without prior written consent.

DISCLAIMER OF WARRANTY ON SOFTWARE AND MATERIALS. You expressly acknowledge and agree that use of the Software and Materials is at your sole risk. FURTHERMORE, SUPER MICRO COMPUTER INC. DOES NOT WARRANT OR MAKE ANY REPRESENTATIONS REGARDING THE USE OR THE RESULTS OF THE USE OF THE SOFTWARE OR MATERIALS IN TERMS OF THEIR CORRECTNESS, ACCURACY, RELIABILITY, OR OTHERWISE. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY SUPER MICRO COMPUTER INC. OR SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF THIS WARRANTY. SHOULD THE SOFTWARE AND/OR MATERIALS PROVE DEFECTIVE, YOU (AND NOT SUPER MICRO COMPUTER INC. OR A SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE) ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICE, REPAIR, OR CORRECTION.

LIMITATION OF LIABILITY. UNDER NO CIRCUMSTANCES INCLUDING NEGLIGENCE, SHALL SUPER MICRO COMPUTER INC. BE LIABLE FOR ANY INCIDENTAL, SPECIAL, OR CONSEQUENTIAL DAMAGES THAT RESULT FROM THE USE OR INABILITY TO USE THE SOFTWARE OR MATERIALS, EVEN IF SUPER MICRO COMPUTER INC. OR A SUPER MICRO COMPUTER INC. AUTHORIZED REPRESENTATIVE HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Any disputes arising between manufacturer and customer shall be governed by the laws of Santa Clara County in the State of California, USA. The State of California, County of Santa Clara shall be the exclusive venue for the resolution of any such disputes. Super Micro's total liability for all claims will not exceed the price paid for the hardware product.

Manual Revision 1.14
Release Date: 5/14/2020

Unless you request and receive written permission from Super Micro Computer, Inc., you may not copy any part of this document.

Information in this document is subject to change without notice. Other products and companies referred to herein are trademarks or registered trademarks of their respective companies or mark holders.

Copyright © 2020 by Super Micro Computer, Inc.
All rights reserved.
Printed in the United States of America

Document Revision History

Date	Revision	Description
05/14/2020	1.14	Initial document.

Contents

1	QoS Overview.....	5
2	Policy-Based QoS.....	6
2.1	Classification and Marking.....	7
3	CoS-Based QoS.....	8
3.1	Egress Queuing	8
3.2	Scheduling.....	9
3.3	Default Priority.....	9
3.4	Bandwidth Management	10
4	Port-Based Rate Limit.....	10
5	HOL Blocking Prevention.....	10
6	Enabling QoS.....	10
7	Configuring Policy-Based QoS.....	11
8	Configuring CoS-Based QoS	17
	Contacting Supermicro.....	22

1 QoS Overview

Typically, networks operate on a best-effort delivery basis providing all traffic equal priority and an equal chance of being delivered in a timely manner. However, during congestion, all traffic has an equal chance of being dropped. The QoS feature allows one to select specific network traffic and prioritize it according to its relative importance to provide preferential treatment. Implementing QoS makes network performance more predictable and bandwidth utilization more effective.

The QoS implementation in Supermicro switches is based on the Differentiated Services (DiffServ) architecture. DiffServ architecture specifies that each packet is classified upon entry into the network. The classification is carried in the IP packet header using six bits from the deprecated IP type of service (ToS) field to carry the classification (class) information. Classification can also be carried in the Layer 2 frame.

- Classification bits in Layer 2 frames:
Layer 2 frame headers contain a class of service (CoS) value as a 3-bit field in the VLAN Header. Layer 2 CoS values range from 0 for low priority to 7 for high priority.

The same forwarding treatment is provided to packets with the same class information and different treatment to packets with different class information. The class information in the packet can be assigned by end hosts or by other switches or routers based on a configured policy, detailed examination of the packet, or both.

Switches and routers use the class information to limit the amount of resources allocated per traffic class. The behavior of a switch/router when handling traffic in the DiffServ architecture is called *per-hop behavior*. All devices along a network path must provide a consistent per-hop behavior in an end-to-end QoS solution.




Figure QoS-1: QoS Model

The QoS Model can be divided into Ingress packet processing and Egress packet processing. Actions at the ingress interface include classifying traffic, policing, and marking: Classifying distinguishes one kind of traffic from another.

Policing determines whether a packet is in or out of profile according to the configured policer. The policer also limits the bandwidth consumed by a flow of traffic.

Marking allows for the differentiation of packets by designating different identifying values, e.g. packets can be marked by setting the IP precedence bits or the IP differentiated services code point (DSCP) in the type of service (ToS) byte.

Actions at the egress interface include queuing and scheduling:

Queuing evaluates the CoS value and determines in which of the eight egress queues to place the packet.

Scheduling services the eight egress queues based on a configured scheduling algorithm.

Parameter	Default Value
QoS Status	Disabled
Class Map	None
Policy Map	None
Default Priority	0
Minimum Bandwidth	0
Maximum Bandwidth	0
Weight	1
Scheduling Algorithm	Strict Queuing
Rate Limit	0
Burst Size	0
HOL	Enabled

The default priority to traffic class queue mapping:

Priority	Traffic Class queue
0	0
1	1
2	2
3	3
4	4
5	5
6	6
7	7

2 Policy-Based QoS

Supernano switch features based on QoS Policies are:

- QoS Classification
- Marking
- Policing

2.1 Classification and Marking

Classification is the process of distinguishing one kind of traffic from another by examining the fields in the packet. Supermicro switches use ACL's to specify the fields in the frame or packet based on which incoming IP traffic is classified.

Classification is enabled only if QoS is globally enabled on the switch. QoS is globally disabled by default, so no classification occurs. In Supermicro switches, classification can be configured for all interfaces of the switch or for particular interfaces only.

After classification, the packet is sent for policing, marking, queuing and scheduling. Marking is the process of setting or modifying values in the classified traffic. In Supermicro switches, marking can be configured using a policy map.

2.1.1.1 ClassMap and PolicyMap

IP standard, IP extended, and Layer 2 MAC access control lists (ACLs) can be used to define a group of packets with the same characteristics (class). Only the permit action of ACL's is permitted for use with QoS.



The Deny and Redirect ACL actions are not applicable for QoS.

After an ACL is associated with a class-map, it can be applied for QoS. When such a configured ACL has a match with a permit action, further classification can be done using a policy map. A policy map specifies the actions to perform for the traffic class of a class-map. Actions can include setting a specific DSCP value or the action to take when the traffic is out of profile.

An ACL must be created for each policy and class-map. If more than one type of traffic needs to be classified, another ACL and class map can be created and associated. This relationship between the ACL, class map and policy map is depicted below.




Figure QoS-2: Relationship: ACL, Policy Map & Class Map

2.1.1.2 Policing

Policing involves creating a policer that specifies the bandwidth limits for the traffic. Each policer specifies the action to take for packets that are in or out of profile. Packets that exceed the limits are out of profile and various actions are carried out by the marker on out of profile packets, which may include dropping the packet or marking down the packet with a new user-defined value.

3 CoS-Based QoS


Supernetwork switch features based on Class of Service (CoS) are:

- Queuing
- Scheduling
- Bandwidth Management
- Default Priority

3.1 Egress Queuing

The CoS priority of a packet is mapped to a traffic class. Supernetwork switches provide support to configure the mapping of CoS priority to a traffic class. Each traffic class is mapped to eight egress queues in the switch.

The traffic class is taken from the CoS value of the ingress packet. If an ingress packet does not have a CoS (untagged packets), the port default priority will be used.



The above figure shows the egress queuing procedure. When a tagged packet with CoS value 3 (packet1) arrives in the switch, the CoS to egress queue mapping for the particular destination port is looked up. Based on CoS to egress queue mapping, packets with CoS value 3 are queued in Queue-3 and transmitted. Similarly, when a tagged packet with CoS value 7 (packet2) arrives in switch, the CoS to egress queue mapping for the particular destination port is looked up. Based on CoS to egress queue mapping, packets with CoS value 7 are queued in Queue-7 and transmitted.

3.2 Scheduling

Supermicro switches support eight CoS queues for each egress port. For each of the eight queues, various types of scheduling can be configured:

Strict Priority

Strict priority scheduling is based on the priority of queues. Packets in a high-priority queue are always sent first and packets in a low-priority queue are not sent until all the high-priority queues are empty.

Round Robin (RR)

Using the round-robin (RR) scheduling algorithm, packets in queues are transmitted in a FIFO manner, i.e. one packet after the other. All queues have the same priority and weight in an RR configuration.

Weighted Round Robin (WRR)

In WRR scheduling, the user specifies a number to indicate the importance (weight) of the queue relative to the other CoS queues. WRR scheduling prevents low-priority queues from being completely neglected during periods of high-priority traffic. The WRR scheduler sends some packets from each queue in turn. The number of packets it sends corresponds to the relative importance of the queue. By using WRR, low-priority queues can send packets even when high-priority queues are not empty.

Deficit WRR

Bandwidth allocation can be unfair when the average packet sizes are different between the queues and their flows. This behavior can result in service degradation for queues with smaller average packet sizes. Deficit Weighted Round Robin (DWRR) is a modified weighted round-robin scheduling that can handle packets of variable size.

3.3 Default Priority

The Class of Service (CoS) priority field is taken from the VLAN header of a received packet. If the received packet does not have a VLAN header, the default port priority is used as the CoS value. Supermicro switches provide an option to configure the default priority.




Figure QoS-4: VLAN Tag and CoS Priority

In the above figures, CoS priority is a 3-bit field in a tagged frame that indicates the frame priority level, ranging from 0 (best effort) to 7 (highest) with 1 representing the lowest priority. These values can be used to prioritize different classes of traffic (voice, video, data, etc.).

For IEEE 802.1Q frames with tag information, the priority value from the header frame is used. For native frames, the default priority of the input port is used. Supermicro switches allow users to configure the default port priority.

Each ingress port on the switch has a single receive queue buffer for incoming traffic. When an untagged frame arrives, it is assigned the value of the port as its port default priority. Tagged frames use the assigned CoS value when it passes through the ingress port.

3.4 Bandwidth Management

Bandwidth limiting is configured at the level of traffic classes. Traffic classes can be assigned minimum bandwidths, maximum bandwidths, and weights. Weights are used to divide the bandwidth proportionally among all traffic classes within a QoS policy, in such a way that a traffic class does not receive more than its maximum bandwidth or less than its minimum bandwidth.

4 Port-Based Rate Limit

Rate limits define which packets conform to or exceed the defined rate based on the following two parameters:

Average rate determines the average transmission rate. Traffic that falls under this rate will always conform.

Burst size specifies in bits (or bytes) per burst how much traffic can be sent within a given unit of time without causing scheduling concerns. It determines how large a traffic burst can be before it exceeds the rate limit.

Traffic that exceeds the rate limit is dropped. Supermicro switches support output rate limits.

5 HOL Blocking Prevention

Supermicro switches provide eight egress queues per port. Each queue has a dynamic packet limit based on the availability of packet buffer memory. When a switch receives packets at a fast rate destined to a particular egress port, its egress port queues become filled up. When the egress queue is full, all packets at ingress are dropped. This phenomenon of dropping ingress packets due to egress port/CoS queue over-subscription is called Head of Line (HOL) blocking.

Supermicro switches provide support to prevent HOL blocking. When HOL blocking prevention is enabled in the switch, it drops packets newly arriving on the ingress if they are destined to an oversubscribed egress port, based on the egress queue threshold. The switch stops dropping ingress packets once it determines the egress queue is not over-subscribed by using specific counters and thresholds. This mechanism ensures fair access to all port buffers.

HOL blocking prevention provides lossy buffer management, however it improves overall system throughput.

6 Enabling QoS

QoS is disabled by default in Supermicro switches. Follow the below steps to enable QoS.

Step	Command	Description
Step 1	configure terminal	Enters the configuration mode
Step 2	set qos enable	Enables QoS on all interfaces
Step 3	End	Exits the configuration mode



The “set qos disable” command disables QoS in the switch.

QoS must be enabled before configuring any of the QoS features.

The example below shows the commands used to enable QoS.

```
SMIS# configure terminal
SMIS(config)# set qos enable
SMIS(config)# end
SMIS(config)# show running-config
Building configuration...
ID  Hardware Version          Firmware  OS   Boot Loader
0   SSE-X3548             1.0.0.0  6   0.0.0.0
vlan 1
ports fx 0/1-24 untagged
ports cx 0/1-3 untagged
exit

setqos enable
```

7 Configuring Policy-Based QoS

Follow the steps below to configure Policy-Based QoS features such as classification, marking and policing.

Step	Command	Description
Step 1	configure terminal	Enters the configuration mode
Step 2	Create MAC Extended or IP Standard or IP Extended ACL. If required, apply ACL to specific Interface(s).	Refer to the ACL Configuration Guide at www.supermicro.com/products/nfo/networking.cfm .
Step 3	class-map <class-map-number(1-65535)>	Creates a class map and enters the class-map configuration mode. <i>class-map-number</i> - QoS class map number in range from 1-65535.

Step 4	<pre>match access-group { mac- access-list ip-access-list } { <acl- index-num (1-65535) > <acl- name> }</pre>	<p>This command specifies the fields in the incoming packets that are to be examined to classify the packets. The IP access group / MAC access group can be used as match criteria.</p> <p><i>mac-access-list</i> - Accesses list created based on MAC addresses for non-IP traffic</p> <p><i>ip-access-list</i> - Accesses list created based on IP addresses. The IP-access list can either be defined as a standard IP-access list or an extended IP-access list.</p> <p><i>acl-index-num</i> - Specifies the ACL index range. The ACL index range for an IP standard ACL is 1 to 1000 and 1001 to 65535 for an IP extended ACL. The ACL index range for a MAC extended ACL is 1 to 65535.</p> <p><i>ACL-name</i> – Specifies the configured ACL name as a string not exceeding 32 characters</p>
Step 5	Exit	Exits the classmap configuration mode.
Step 6	<pre>policy-map <policy-map- number(1-65535)></pre>	<p>Creates a policy map and enters the policy-map configuration mode.</p> <p><i>policy-map-number</i> - QoS policy map number</p>
Step 7	<pre>class <class-map-number(1- 65535)></pre>	<p>This command defines a traffic classification for the policy to act upon. The class-map-number that is specified in the policy map ties the characteristics for that class to the class map and its match criteria as configured with the class-map global configuration command. Upon execution of the class command, the switch enters the policy-map class configuration mode.</p> <p><i>class-map-number</i> – The class map number to associate the policy, in range of 1-65535</p>
Step 8	<pre>set {cos<new-cos(0-7)> ipdscp<new-dscp(0-63)> ip precedence <new-precedence(0- 7)>}</pre>	<p>(Optional) Configures the in-profile action by setting a class of service (CoS), differentiated services code point (DSCP), or IP-precedence value in the packet.</p> <p><i>cos</i> - New COS value assigned to the classified traffic, in range of 0-7</p> <p><i>ipdscp</i> - New DSCP value assigned to the classified traffic, in range of 0-63</p> <p><i>ip precedence</i> - New IP-precedence value assigned to the classified traffic, in range of 0-7</p>

Step 9	<pre> police <rate-Kbps(64-1048572)> exceed-action {drop policed- dscp-transmit <new-dscp(0-63)>} </pre>	<p>(Optional) Configures a policer for the classified traffic. This command also specifies the action to be taken if the specified rate is exceeded or if there is no match for the policy configured.</p> <p>rate-kbps- Average traffic rate in kilobitsper second (Kbps), in range 64-1048572</p> <p>exceed-action - Indicates the action of the switch when the specified rate is exceeded.</p> <p>drop - drops the packet</p> <p>policed-dscp-transmit - changes the differentiated services code point (DSCP) of the packet to that specified in the policed-DSCP map and then sends the packet. The DSCP range is 0-63.</p>
Step 10	End	Exits the configuration mode.
Step 11	<pre> show class-map [<class-map- num(1-65535)>] show policy-map [<policy-map- num(1-65535)> [class <class- map-num(1-65535)>] </pre>	<p>Displays the classmap configuration.</p> <p>Displays the policy map configuration.</p>



ACL cannot be modified unless it is removed from the class-map.

For modifying an ACL associated with a classmap, follow the steps below:

- 1) Remove policy map
- 2) Remove classmap
- 3) Modify the ACL
- 4) Re-create the classmap
- 5) Re-create the policymap

If required, an ACL's association with an interface must be configured before the "class-map" configuration, i.e. after associating the ACL with a classmap using the "match" command, the ACL cannot be associated with an interface.

These commands either delete the particular configuration or reset it to its default value.

```
no class-map <class-map-number(1-65535)>
```

```
no policy-map <policy-map-number(1-65535)>
```

```
no class <class-map-number(1-65535)>
```

Before deleting a classmap, any policy map associated with it must first be deleted.

The example below shows the commands used to configure QoS classification, marking and policing.

Example 1: Classification and Marking

Create a Layer 2 MAC ACL with two permit statements and attach it to an ingress interface. The first permit statement allows traffic from the host with a MAC address of 00:30:48:14:c8:29 to be sent to any

```

host.
SMIS# configure terminal
SMIS(config)# mac access-list extended mac1
SMIS(config-ext-macl)# permit host 00:30:48:14:c8:29 any
SMIS(config-ext-macl)# exit
SMIS(config)# set qos enable
SMIS(config)# interface Fx 0/3
SMIS(config-if)# mac access-group mac1
SMIS(config-if)# exit
SMIS(config)# class-map 5
SMIS(config-cmap)# match access-group mac-access-list mac1
SMIS(config-cmap)# exit
SMIS(config)# policy-map 5
SMIS(config-pmap)# class 5
Existing Polycmap configurations have been deleted. Please apply the polycmap to make it active.
SMIS(config-pmap-c)# set cos 6
SMIS(config-pmap-c)# end
SMIS(config)# mac access-list extended mac2
SMIS(config-ext-macl)# permit host 00:b0:d0:86:bb:f7 any
SMIS(config-ext-macl)# exit
SMIS(config)# interface Fx 0/3
SMIS(config-if)# mac access-group mac2
SMIS(config-if)# exit
SMIS(config)# class-map 10
SMIS(config-cmap)# match access-group mac-access-list mac2
SMIS(config-cmap)# exit
SMIS(config)# policy-map 10
SMIS(config-pmap)# class 10
Existing polycmap configurations have been deleted. Please apply the polycmap to make it active.
SMIS(config-pmap-c)# set cos 7
SMIS(config-pmap-c)# end
SMIS# show policy-map
DiffServ Configurations:
-----
Quality of Service has been enabled
Policy Map 5 is active
Class Map: 5
-----
In Profile Entry
-----
In profile action      : policed-cos6
Policy Map 10 is active
Class Map: 10
-----
In Profile Entry
-----
In profile action      : policed-cos7

```

SMIS# show class-map

DiffServ Configurations:

Class map 5

Filter ID : mac1

Filter Type : MAC-FILTER

DiffServ Configurations:

Class map 10

Filter ID : mac2

Filter Type : MAC-FILTER

SMIS# show running-config

Building configuration...

ID	Hardware	Version	Firmware	OS	Boot Loader
0	SSE-X3548		1.0.0.0	6	0.0.0.0

vlan 1

ports fx 0/1-24 untagged

ports cx 0/1-3 untagged

exit

mac access-list extended mac1

permit host 00:30:48:14:c8:29 any

exit

mac access-list extended mac2

permit host 00:b0:d0:86:bb:f7 any

exit

interface Fx 0/3

mac access-group mac1

mac access-group mac2

exit

setqos enable

class-map 5

match access-group mac-access-list mac1

exit

class-map 10

match access-group mac-access-list mac2

exit

policy-map 5

class 5

setcos 6

exit

exit

policy-map 10

class 10

```
setcos 7
```

```
exit
```

```
exit
```

Example 2: Policing

Create a policy map for the switch without attaching it to an ingress interface. In the configuration, the IP standard ACL permits traffic from network 20.1.0.0. For traffic matching this classification, the DSCP value in the incoming packet is trusted. If the matched traffic exceeds an average traffic rate of 4800 bps, its DSCP is marked down to a value of 10 and transmitted.

```
SMIS# configure terminal
```

```
SMIS(config)# ip access-list standard 1
```

```
SMIS(config-std-nacl)# permit 20.1.0.0 255.255.0.0 any
```

```
SMIS(config-std-nacl)# exit
```

```
SMIS(config)# set qos enable
```

```
SMIS(config)# class-map 1
```

```
SMIS(config-cmap)# match access-group ip-access-list 1
```

```
SMIS(config-cmap)# exit
```

```
SMIS(config)# policy-map 1
```

```
SMIS(config-pmap)# class 1
```

Existing policymap configurations have been deleted. Please apply the policymap to make it active.

```
SMIS(config-pmap-c)# police 500000 exceed-action policed-dscp-transmit 10
```

```
SMIS(config-pmap-c)# end
```

```
SMIS# show policy-map
```

DiffServ Configurations:

Quality of Service has been enabled

Policy Map 1 is active

Class Map: 1

Out Profile Entry

Metering on

burst bytes/token size : 6

Refresh count : 500000

Out profile action : policed-dscp 10

```
SMIS# show class-map
```

DiffServ Configurations:

Class map 1

Filter ID : 1

Filter Type : IP-FILTER

```
SMIS# show running-config
```

Building configuration...

ID	Hardware Version	Firmware	OS	Boot Loader
0	SSE-X3548	1.0.0.0	6	0.0.0.0


```

vlan 1
ports fx 0/1-24 untagged
ports cx 0/1-3 untagged
exit
ip access-list standard 1
permit 20.1.0.0 255.255.0.0 any
exit
setqos enable
class-map 1
match access-group ip-access-list 1
exit
policy-map 1
class 1
police 500000 exceed-action policed-dscp-transmit 10
exit
exit

```

8 Configuring CoS-Based QoS

Follow the steps below to configure CoS-Based features such as default priority, scheduling and bandwidth.

Step	Command	Description
Step 1	configure terminal	Enters the configuration mode
Step 2	vlan map-priority <priority value(0-7)> traffic-class <Traffic class value(0-7)>	<p>Maps a priority to a traffic class in the switch. The frame received with the configured priority will be processed in the configured traffic class.</p> <p>Priority- Priority of the packet, in range of 0-7.</p> <p>Class –Traffic class in range of 0-7.</p>
Step 3	interface <interface-type><interface-id> or interface range <interface-type><interface-id>	<p>(Optional) Enters the interface configuration mode.</p> <p>interface-type – may be any of the following: fx-ethernet – fx cx-ethernet – cx</p> <p>interface-id is in slot/port format for all physical interfaces.</p>

		<p>To configure multiple interfaces, use the “interface range ...” command. To provide a range use a hyphen (-) between the start and end interface numbers. E.g.: int range fx 0/1-10</p> <p>To provide multiple interfaces or ranges, separate with a comma (,). E.g.: int range fx 0/1-10, fx 0/20</p> <p>If multiple interfaces are provided, the next step will perform the particular configuration on all these interfaces.</p>
Step 4	switchport priority default <priority value(0-7)>	(Optional) Configures the default priority for the interface in range of 0-7.
Step 5	cosq scheduling algorithm { strict rr wrr deficit }	(Optional) Configures the QoS Egress queue scheduling algorithm. strict - strict rr - round robin wrr - weighted round robin (WRR) deficit – deficit WRR
Step 6	traffic-class <integer(0-7)> weight <integer(0-15)> [minbandwidth<integer(64-16777152)>] [maxbandwidth<integer(64-16777152)>]	(Optional) Configures the egress queue minimum and maximum bandwidth. weight - Configures the queue weights in range of 0-15 minbandwidth - Configures the minimum bandwidth for the queue in range of 64-16777152 maxbandwidth - Configures the maximum bandwidth for the queue in range of 64-16777152
Step 7	End	Exits the configuration mode.
Step 8	show vlan port config port [<interface-type><interface-id>] show vlan traffic-classes	Displays the port default priority configuration. Display the traffic class and egress queue mapping.



The “no cosq scheduling algorithm” resets the CoS queue scheduling algorithm configuration to its default value of *strict*.

The “no traffic-class [<integer(0-7)>] [weight] [minbandwidth] [maxbandwidth]” command resets the minimum/maximum bandwidth configuration to its default value of 0 and weight to 1.

The “no switchport priority default” command resets the default priority configuration to its default value of 0.

The “no vlan map-priority <priority value (0-7)>” command resets the egress CoS queue mapping to its default value.

The example below shows the commands used to configure QoS default priority, scheduling and bandwidth.

Example 1: Default Priority

```
SMIS# configure terminal
SMIS(config)# interface Fx 0/10
SMIS(config-if)# switchport priority default 5
SMIS(config-if)# end
SMIS# show vlan port config port Fx 0/10
```

Vlan Port configuration table

```
-----
Port Fx0/10
Port Vlan ID          : 1
Port Access Vlan ID   : 1
Port Acceptable Frame Type : Admit All
Port Ingress Filtering : Disabled
Port Mode              : Hybrid
Port Gvrp Status       : Disabled
Port Gmrp Status       : Disabled
Port Gvrp Failed Registrations : 0
Gvrp last pdu origin   : 00:00:00:00:00:00
Port Restricted Vlan Registration : Disabled
Port Restricted Group Registration : Disabled
Mac Based Support      : Disabled
Port-and-Protocol Based Support : Enabled
Default Priority       : 5
Filtering Utility Criteria : Default
Allowed Vlans on Trunk : 1-4069
Trunk Native Vlan Id   : 0
-----
```

Example 2: Scheduling

The example below shows the commands used to configure the QoS scheduling algorithm.

```
SMIS# configure terminal
SMIS(config)# set qos enable
SMIS(config)# interface Fx 0/8
SMIS(config-if)# cosq scheduling algorithm wrr
```

```
SMIS(config-if)# end
SMIS# show cosq algorithm
CoSq Algorithm
```

```
-----
Interface   Algorithm
-----
Fx0/1      StrictPriority
Fx0/2      StrictPriority
Fx0/3      StrictPriority
Fx0/4      StrictPriority
Fx0/5      StrictPriority
Fx0/6      StrictPriority
Fx0/7      StrictPriority
Fx0/8      WeightedRoundRobin
Fx0/9      StrictPriority
Fx0/10     StrictPriority
Fx0/11     StrictPriority
Fx0/12     StrictPriority
Fx0/13     StrictPriority
Fx0/14     StrictPriority
Fx0/15     StrictPriority
Fx0/16     StrictPriority
Fx0/17     StrictPriority
Fx0/18     StrictPriority
Fx0/19     StrictPriority
Fx0/20     StrictPriority
Fx0/21     StrictPriority
Fx0/22     StrictPriority
Fx0/23     StrictPriority
Fx0/24     StrictPriority
Cx0/1      StrictPriority
Cx0/2      StrictPriority
Cx0/3      StrictPriority
Cx0/3      StrictPriority
```

Example 3: Egress Bandwidth

```
SMIS# configure terminal
SMIS(config)# set qos enable
SMIS(config)# interface Fx 0/15
SMIS(config-if)# traffic-class 6 weight 7 minbandwidth 6400 maxbandwidth 6400000
SMIS(config-if)# end
SMIS# show cosq weights-bw interface Fx 0/15
CoSq Weights and Bandwidths
```

```
-----
Interface CoSqliCoSqWeightMinBwMaxBw
-----
Fx0/15   0    1    0    0
Fx0/15   1    1    0    0
```

```
Fx0/15 2 1 0 0
Fx0/15 3 1 0 0
Fx0/15 4 1 0 0
Fx0/15 5 1 0 0
Fx0/15 6 7 6400 6400000
Fx0/15 7 1 0 0
```

Example 4: Egress Queue

```
SMIS# configure terminal
SMIS(config)# vlan map-priority 2 traffic-class 7
SMIS(config)# end
SMIS# show vlan traffic-classes
```

Priority to Traffic Class Queue Mapping

```
-----
Priority      Traffic Class Queue
-----
0            0
1            1
2            7
3            3
4            4
5            5
```

Contacting Supermicro

Headquarters

Address: Super Micro Computer, Inc.
980 Rock Ave.
San Jose, CA 95131 U.S.A.
Tel: +1 (408) 503-8000
Fax: +1 (408) 503-8008
Email: marketing@supermicro.com (General Information)
support@supermicro.com (Technical Support)
Web Site: www.supermicro.com

Europe

Address: Super Micro Computer B.V.
Het Sterrenbeeld 28, 5215 ML
's-Hertogenbosch, The Netherlands
Tel: +31 (0) 73-6400390
Fax: +31 (0) 73-6416525
Email: sales@supermicro.nl (General Information)
support@supermicro.nl (Technical Support)
rma@supermicro.nl (Customer Support)
Web Site: www.supermicro.com.nl

Asia-Pacific

Address: Super Micro Computer, Inc.
3F, No. 150, Jian 1st Rd.
Zhonghe Dist., New Taipei City 235
Taiwan (R.O.C)
Tel: +886-(2) 8226-3990
Fax: +886-(2) 8226-3992
Email: support@supermicro.com.tw
Web Site: www.supermicro.com.tw